



When introducing new filled kegs to the line always remove partially filled keg and move it back to position "A" nearest the air distributor.

Important: If keg "A" feels empty but keg "B" appears full, move keg "B" back to position "A" and place new keg "B" position, for if even a small portion of keg "B" has been drawn off a head space will be present in this keg and by placing a full keg behind it you will be introducing beer into this airspace creating excessive foaming in the kegs.