



1-877-420-4305

# FOB Operating Instructions

## Changing the Keg



**Step 1** Disconnect empty keg and tap new keg.

**Step 2** Push vent until chamber is full of clear beer.



**Step 3** Turn lever to UP position to lift float.



**Step 4** Turn lever to DOWN position to pour beer.

## Cleaning the Beer Line



**Step 1** Turn lever to UP position before cleaning.

**Step 2** Clean beer line.



**Step** Turn lever to DOWN position to pour beer.