

WHEN KEG IS EMPTY:

- When keg is empty, ball in FOB "drops" and flow at the faucet stops
- Disconnect the keg coupler from the empty keg and connect it to a full keg



STEP 1: RE-FILL FOB:

- Press down slowly on Vent Button until FOB fills with fresh beer
- Collect overflow in waste container and discard



STEP 2: RESET FLOAT:

- Ensure faucet at beer tower is closed before resetting the float
- Push Black Reset Knob FULLY IN
- Float (White Ball) will rise to the top of FOB



STEP 3: RESET FOB:

- Pull Black Reset Knob OUT until you feel it "click" into place
- Resume pouring FRESH COLD BEER

